## SNOM for the optical characterization of photonic crystals structures

D. Néel, T. Benyattou, R. Orobtchouk

Laboratoire de physique de la matière, Insa de Lyon, Bâtiment Blaise Pascal, 69621 Villeurbanne Cedex, France P. Dumon, D. Van Thourhout Department of Information— Technology-IMEC, University of Gent, Sint-Pietersnieuwstraat 41, B-9000 Gent, Belgium

The characterization methods by classical microscopy are not well adapted to the study of photonic crystals structures because of their lack of resolution due to diffraction. Scanning Near-field Optical Microscopy (SNOM) appears like a unique way of characterization since it allows a local mapping of the electromagnetic field of a component under working conditions, with a resolution less than the wavelength. These field maps make it possible to detect the defects and make a return on the technology and the design in order to optimise the devices.

In this work, we analyse the guided light within the basic building blocks of photonic crystals-based optical circuits on SOI, working in telecom wavelengths (1.3-1.6  $\mu$ m). We will present results on various devices: a W1 guide, a 60°-bended W1 guide and a Y-junction. SNOM observations show the apparition of standing waves in the photonic crystals guides. Realizing a Fourier transform and applying a high pass filter to the optical image, we can highlight the presence of the Bloch wave propagating in the guides.

## Purcell Enhanced and Inhibited Emission in 3D Photonic Crystals

Ivan Nikolaev<sup>1</sup>, Peter Lodahl<sup>1</sup>, Floris van Driel<sup>2</sup>, Karin Overgaag<sup>2</sup>, and Willem Vos<sup>1</sup>
1) Complex Photonic Systems (COPS), Department of Science and Technology and MESA+ Research Institute, University of Twente, 7500 AE Enschede, The Netherlands.
2) Debye Institute, Chemistry of Condensed Matter, Utrecht University, 3508 TA Utrecht, The Netherlands.

Control over spontaneous emission of light is essential to quantum optics and to diverse applications such as miniature lasers, LEDs, and single-photon sources for quantum information. We present experiments on emission from CdSe quantum dots (QDs) in 3D inverse opals. In time-resolved experiments, we observe that the photonic crystals

control the emission decay rate of the QDs, demonstrating both broadband inhibition and enhancement [1]. For the first time we successfully interpret the emission dynamics of an *ensemble* of emitters (see Fig.): decay curves are modelled with a distribution of decay rates (curves). From this analysis we conclude that individual QDs experience even larger decay-rate modifications than the ensemble average.

1 - inhibited decay rate
2 - reference sample
3 - enhanced decay rate
2

No. 1000

1 3 - enhanced decay rate
2 - reference sample
3 - enhanced decay rate

Time [ns]

[1] Nature 430, 654 (2004); arxiv.org/physics/0410056.